

# SOLUS

## Coppice Real Log Set - Fitting Guide



Remove any existing logs or fuel elements from the fire and use a screwdriver to remove the screws that secure the clear plastic sheet.



Remove the clear plastic sheet from the fire and discard. This is not needed when installing a Coppice Real Log Set.



Carefully lift the Coppice Real Log Set by the base - do not lift by the logs - and position into the fire where the clear plastic sheet once sat.



Turn the fire on to determine the level of fuel bed illumination. If there are bright spots, use the bag of bark chippings to scatter around the logs.